


aIVR_DB16 --- Demo Board User Manual

- PART NO. : aIVR_DB16
- PCB size : 68x 63 mm
- PCB No. : 8198
- For Body : aIVR4208 / aIVR2104 / aIVR1004


aIVRxxx Series IC : Built in 8 bits CPU + VOICE OTP


Part No.	Durations	I/O	Memory size	VCC	PIN
aIVR4208	42''	8 [PB0 ~ PB3] [PC0 ~ PC3]	1M bits	2.2~3.6V	16
aIVR2104	21''	4 [PB0 ~ PB3]	512K bits	2.2~3.6V	16
aIVR1004	10''	4 [PB0~PB3]	256K bits	2.2~3.6V	16

aIVR4208		aIVR2104 aIVR1004		aIVR2104 aIVR1004		aIVR4208	
PIN	Name	PIN	Name	PIN	Name	PIN	Name
1	PC2	1	NC	9	NC	9	PC1
2	PC3	2	NC	10	NC	10	PC0
3	VDD	3	VDD	11	VddA	11	VddA
4	Vout2	4	Vout2	12	OSC	12	OSC
5	Vout1	5	Vout1	13	RSTB	13	RSTB
6	NC	6	NC	14	PB0	14	PB0
7	VSS	7	VSS	15	PB1	15	PB1
8	PB3	8	PB3	16	PB2	16	PB2



Demo Board Circuit :





1. Push the [aIVR4208/2104/1004 IC] to the TEXTTOOL SOCKET
2. PWM or DAC selection
3. connected speaker to [PWM] or [DAC] pin
4. I/O setup :
PB3-PB2-PB1-PB0-PC3-PC2-PC1-PC0 I/O setup by DIP SW-8
Output : please set to [on]
Input : please set to [off]
5. connected battery 3V & power on
6. push the [Reset] key for IC Reset
7. **aIVRxxx series IC functions testing**